




# How to Farberware FSTO100

If the toaster oven does not heat up properly. This guide will help you fix the most common issue that arises with the heating mechanism.

Written By: Tony Wang



## INTRODUCTION

Wire leads are attached inside to heat the toaster oven. Use this guide to repair the heating mechanism to regain use of your toaster oven.


---



### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — How to Farberware FSTO100



- ❗ If one of the heating mechanisms isn't working, make sure all wire leads are attached inside the toaster oven.
  - When a broken lead is found, reattach by removing the screw at its original attachment point.

## Step 2



- Make sure that the lead is attached and in contact.



## Step 3



- Retighten screw to secure lead.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-06 06:10:46 PM.